

MMS Sender engine BETA 1.0

{jfalternative}46|content|There are no translations available{/jfalternative}

You can download the MMS send module for free and install it on your MMS foxbox. The MMS send module, is able to send multimedia messages using MM1 interface .

The MMS send Module, is composed by two parts:

- The media encoder (SMIL document encoder)
- The sener engine

The module requires that your MMS foxbox is configured as described here to work.

To install it, simply download this ZIP package , unzip it and place the MMS_out folder inside your MMS foxbox, in /mnt/flash/root/ using FTP or SSH with default username: root password: pass.

Once the folder has been loaded into the foxbox point your web browser to http://<ip foxbox>/MMS_out/mms_send.php.

A window like this one will appear:

Fill in the form a press Send.

Download it here ZIP package.

LIMITATIONS OF THIS BETA:

- The module can encode just PNG images other format are not properly encoded
- The encoder takes between 15-20sec to prepare the message to send
- Attache text is limited in character size
- You cannot add more that one photo to the SMIL document